

Alle temperaturer er gennemsnitstemperaturer over året

		Grader over straf zone for returtemperatur (rød kolonne)																	
		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
Fremløbstemp.		Retur temp. - Neutral zone	Retur temp. - Gevinist zone	Retur temp. - Straf zone															
70	<30,0	30,0 - 37,0	>37,0	1,01	1,02	1,03	1,04	1,05	1,06	1,07	1,08	1,09	1,10	1,11	1,12	1,13	1,14	1,15	1,16
69	<30,0	30,0 - 37,0	>37,0	1,01	1,02	1,03	1,04	1,05	1,06	1,07	1,08	1,09	1,10	1,11	1,12	1,13	1,14	1,15	1,16
68	<30,0	30,0 - 37,0	>37,0	1,01	1,02	1,03	1,04	1,05	1,06	1,07	1,08	1,09	1,10	1,11	1,12	1,13	1,14	1,15	1,16
67	<30,0	30,0 - 37,0	>37,0	1,01	1,02	1,03	1,04	1,05	1,06	1,07	1,08	1,09	1,10	1,11	1,12	1,13	1,14	1,15	1,16
66	<30,0	30,0 - 37,0	>37,0	1,01	1,02	1,03	1,04	1,05	1,06	1,07	1,08	1,09	1,10	1,11	1,12	1,13	1,14	1,15	1,16
65	<30,0	30,0 - 37,0	>37,0	1,01	1,02	1,03	1,04	1,05	1,06	1,07	1,08	1,09	1,10	1,11	1,12	1,13	1,14	1,15	1,16
64	<30,5	30,5 - 37,5	>37,5	1,01	1,02	1,03	1,04	1,05	1,06	1,07	1,08	1,09	1,10	1,11	1,12	1,13	1,14	1,15	1,16
63	<31,0	31,0 - 38,0	>38,0	1,01	1,02	1,03	1,04	1,05	1,06	1,07	1,08	1,09	1,10	1,11	1,12	1,13	1,14	1,15	1,16
62	<31,5	31,5 - 38,5	>38,5	1,01	1,02	1,03	1,04	1,05	1,06	1,07	1,08	1,09	1,10	1,11	1,12	1,13	1,14	1,15	1,16
61	<32,0	32,0 - 39,0	>39,0	1,01	1,02	1,03	1,04	1,05	1,06	1,07	1,08	1,09	1,10	1,11	1,12	1,13	1,14	1,15	1,16
60	<32,5	32,5 - 39,5	>39,5	1,01	1,02	1,03	1,04	1,05	1,06	1,07	1,08	1,09	1,10	1,11	1,12	1,13	1,14	1,15	1,16
59	<33,0	33,0 - 40,0	>40,0	1,01	1,02	1,03	1,04	1,05	1,06	1,07	1,08	1,09	1,10	1,11	1,12	1,13	1,14	1,15	1,16
58	<33,5	33,5 - 40,5	>40,5	1,01	1,02	1,03	1,04	1,05	1,06	1,07	1,08	1,09	1,10	1,11	1,12	1,13	1,14	1,15	1,16
57	<34,0	34,0 - 41,0	>41,0	1,01	1,02	1,03	1,04	1,05	1,06	1,07	1,08	1,09	1,10	1,11	1,12	1,13	1,14	1,15	1,16
56	<34,5	34,5 - 41,5	>41,5	1,01	1,02	1,03	1,04	1,05	1,06	1,07	1,08	1,09	1,10	1,11	1,12	1,13	1,14	1,15	1,16
55	<35,0	35,0 - 42,0	>42,0	1,01	1,02	1,03	1,04	1,05	1,06	1,07	1,08	1,09	1,10	1,11	1,12	1,13			
54	<35,5	35,5 - 42,5	>42,5	1,01	1,02	1,03	1,04	1,05	1,06	1,07	1,08	1,09	1,10	1,11	1,12	1,13			
53	<36,0	36,0 - 43,0	>43,0	1,01	1,02	1,03	1,04	1,05	1,06	1,07	1,08	1,09	1,10	1,11					
52	<36,5	36,5 - 43,5	>43,5	1,01	1,02	1,03	1,04	1,05	1,06	1,07									
51	<37,0	37,0 - 44,0	>44,0	1,01	1,02	1,03	1,04	1,05	1,06										
50	<37,5	37,5 - 44,5	>44,5	1,01	1,02	1,03	1,04	1,05	1,06										

For hver grad returtemperaturen er over straf zonen (rød kolonne >37,0 til >44,5 °C) ganges prisen for MWh forbruget fra årsopgående faktor